



REPAIR KIT – INSTRUCTIONS FOR USE

For repairing slight damage (splits in the laminate, scratches, open joints). The desired colour is obtained by mixing the pigments with the basic paste.

Instructions

- For optimal adhesion, make sure that the area is clean and free of oil, wax or grease. You
- may need to use a chisel to remove any stray pieces attached to the surface.
- Tape off the edges of the damaged area with adhesive tape.
- Available REPAIR KITS:

REPAIR KIT No.	Possible colour combinations
KIT 1	beige to dark-brown
KIT 2	red to grey and white
KIT 3	green to blue and white

- Find the optimal colour match for your product on the back of the package insert. Using the colour strip, select the colour that best matches the design of the damaged surface. The mixing ratio for the lightest and darkest colour hues is specified on the colour strip. Adjust the mixing ratio until it appears to match the colour shade of the floor. Mix the basic paste (large tube) with the colour pigment to produce a uniform mixture. You can adjust the colour hue by adding more pigment one drop at a time. We recommend that you use only one drop per colour correction. **Before using pigment, please shake well.**
Once mixed, the paste must be used within a few minutes.
- Position a scraper at the edge of the damaged area. Press the scraper with the REPAIR KIT paste firmly onto the surface while slowly dragging it across the damaged area. This will ensure that the damaged area is evenly filled with REPAIR KIT.
In the case of deeper damage, you will need to apply several layers of REPAIR KIT. You can apply as many layers as necessary to even it up with the surface. Let the paste dry for about 10 minutes between applications of individual layers.

Depending on the depth of the damage, the paste may shrink during the hardening process and require follow-up processing.

- Using a clean scraper, remove excess paste from the damaged area. Before the paste hardens, wipe away any messy spots with a damp cloth. Hardened REPAIR KIT residue is easily removed with acetone. Use the acetone sparingly, however, or you might remove too much paste or start to dissolve the paste you applied.



- Allow repaired areas to harden for at least 1 hour before using.

General information

- REPAIR KIT is not affected by household products such as detergents.
- REPAIR KIT does not adhere to the uppermost surface, but binds itself with the base papers and core board.
- The area sealed with REPAIR KIT hardens thoroughly, making REPAIR KIT the ideal solution for repairing laminate flooring.
- Because REPAIR KIT begins to harden as soon as it comes into contact with oxygen, always close the tube immediately after use.
- Keep REPAIR KIT safe from freezing temperatures and out of the reach of children.
- The basic paste and pigments are water-based and solvent-free.

REPAIR KIT	Modified	08/09	INF07-GB
	by		Page 1/2